



Step 1
Trowel Modified Thin-Set



Step 2
Place Silicone On Perimeter Of Drain



Step 3
Ensure That Shower Base Is Firmly Set



Step 4
Clamp Shower Base To Drain



Step 5
Trowel Thin-Set & Install Tile As Usual



Step 6
Step Back & Admire Your Craftsmanship